10ft W x 8ft H
Back To Back Backdrop
# Assembling Manual

Content

*Below contents are needed to build one back to back Backdrop.*

Backdrop Panel Set (need 1 set for wall #1 & 1 set for wall #2)

The following backdrop panel and component sets applied for Gold Sylfirm X, Iridescent Exosome, Crinkle Vinyl Viviscal PRO, Black BENEV]

Left Top Panel (3ft x 4ft)	Middle Top Panel (4ft x 4ft)	Right Top Panel (3.ft x 4ft)
x1	x1	x1

Left Bottom Panel (3ft x 4ft)	Middle Bottom Panel (4ft x 4ft)	Right Bottom Panel (3ft x 4ft)
x1	x1	x1

Endcap Panel set

Endcap Panel without Door (2.5ft x 8ft)	Endcap Panel with Door (2.5ft x 8ft)
x1	x1

Backdrop Panel Component Set (need 1 set for wall #1 & 1 set for wall #2)

Power drill and drill bits are not included.

Large Connector	Small Connector	Screw (2 inch (50 mm))	Sandbags 50 lbs / leg (each)
x1	x2	x6	x3

| Medium Connector	Lock		
x4	x7		

Content

*Below contents are needed to build one back to back Backdrop.

Miracu Purple Backdrop Panel Set

The following backdrop panel and component sets applied for Miracu Purple Backdrop ONLY

Left Top Panel
(4ft x 4ft)

x1

Middle Top Panel
(2ft x 4ft)

x1

Right Top Panel
(4ft x 4ft)

x1

Left Bottom Panel
(4ft x 4ft)

x1

Middle Bottom Panel
(2ft x 4ft)

x1

Right Bottom Panel
(4ft x 4ft)

x1

Endcap Panels

Endcap Panel
without Door
(2.5ft x 8ft)

x1

Endcap Panel
with Door
(2.5ft x 8ft)

x1

Miracu Purple Backdrop Panel Components

Power drill and drill bits are not included.

Small
Connector

x1

Large
Connector

x2

Screw
(2 inch (50 mm))

x6

Sandbags
50 lbs / leg (each)

x3

Medium
Connector

x4

Lock

x7

How to Assemble

Step A: Build from the Endcap Panel Without Door

Right Top Panel (Wall #2)

Left Top Panel (Wall #1)

Right Bottom Panel (Wall #2)

Left Bottom Panel (Wall #1)

1. Place the Left Bottom Panel (Wall #1). Open the attached leg and slide in one sandbag in between the blue area to prevent falling.
2. Insert a small connector into the Left Bottom Panel (Wall #1). Connect the Left Top Panel (Wall #1) on top of it.
3. Place the Endcap Panel Without Door and connect it to the Left Panels (Wall #1) by drilling a screw into the targeted area.
4. Repeat step 1 for the opposite wall panel (Wall #2) and move it close to the Endcap Panel.
5. Repeat step 2 and connect it to Endcap Panel by drilling a screw into the targeted area.
6. Once it is completed, lock each conjuncted section with the "Lock" by rotating the handle.

**Picture below shows the final of Step A**

Step B: Build the middle pannels

7. Insert two Middle Connectors to the end of the panels (Wall #1) that were built in the Step A.
8. Connect the Middle Bottom Panel to the panel that was built in Step A. Open the attached leg and put one sandbag on the blue area to prevent falling.
9. Insert a Large Connector into the Middle Bottom Panel and put the to Middle Top Panel on top of it. *For Miracu Purple Backdrop, use the Small Connector that came with its set.*
10. Repeat the step 7-9 for the opposite wall panels (Wall #2).
11. Insert medium connectors both on top and bottom panels (Wall #1 & Wall #2).
12. Once it is completed, lock each conjuncted section with the "Lock" by rotating the handle.

**Picture below shows the final of Step B**

How to Assemble

## Step C: Build the last panels

13. Connect the Right Bottom Panel (Wall #1) to the panel built in Step A. Open the attached leg and put one sandbag on the blue area to prevent falling.
14. Insert a small connector into the Right Bottom Panel (Wall #1) and put the Right Top Panel (Wall #1) on.
15. Repeat the step 13-14 for the opposite side wall panels (Wall #2).
16. Once it is completed, lock each conjuncted section with the "Lock" by rotating the handle.

Picture below shows the final of step C

Step D: Install the Endcap Panel with Door.

17. Fit the Endcap Panel with Door to the panel built in step C. Work from the inside area, drill 3 screws along the left side of the door first.
18. Open the door from the inside and drill another 3 screws along theother other side of the Endcap Panel.
   (*drill the screw on the circled areas)

Picture below shows final design

How to Disassemble - Sequin Wall (4 Crates Total)

Right top and bottom endcap panels
(Faced up) *Not Used in this Build

Left top and bottom endcap panels
(Faced down) *Not Used in this Build

Cardboard
(Skip in the case of no cardboard)

Right top panel
(sequin faced down)

*Medium connector x1, Small connector x1
Endcap connector x1, Lock x3*

Cardboard

Right bottom panel
(sequin faced up)

Middle top panel
(sequin faced down)

*Large connector x1,
Medium connector x2, Lock x3*

Cardboard

Middle bottom sequin panel
(sequin faced up)

Left top panel
(sequin faced down)

*Medium connector x1, Small connector x1
Endcap connector x1, Lock x3*

Cardboard

Left bottom sequin panel
(sequin faced up)

Crate

How to Disassemble

– Side End Caps (1 crate with 4 panels in it)

Endcap Panel with Door (Faced down)

Packing Foam

Endcap Panel without Door (Faced up)

Packing Foam

Endcap Panel with Door (Faced down)

Packing Foam

Endcap Panel without Door (Faced up)

Crate

6ft W x 6ft H
Sylfirm X Navy Triangle Panel
Assembling Manual

Package Contents

Sylfirm X Navy Triangle Panel

Top
Triangle Panel
(3ft x 3ft)

Bottom
Triangle Panel
(6ft x 3ft)

x1

x1

Panel Components

Connector

Sandbag
50 lbs / leg (each)

x1

x1

How to Assemble

1. Place the Bottom Triangle Panel. Open the attached leg and overlap the legs. Slide in one sandbag between the blue areas to prevent falling.
2. Insert the Connector into the bottom triangle panel.
3. Connect the Top Triangle Panel on top.

Picture below shows final design

Back

3ft W x 5.5ft H
Viviscal PRO Display Shelf
Assembling Manual

Proven To Grow

Package Contents

Viviscal PRO Shelf

Folded Shelf Pannel

Shelf

x4

x1

Shelf Components

Key

Sandbag
50 lbs / leg (each)

x8

x1

How to Assemble

1. Unfold the Viviscal PRO Shelf Panel.
2. Slide down the locks in the back of the panel to secure the panel.
3. Open the attached leg and overlap two legs. Slide in a sandbag between the blue area to prevent falling.
4. Insert the shelves horizontally into each hole.
5. Insert the keys vertically to secure the shelves.

Picture below shows the final design

Back

4ft W x 4ft H
Sylfirm X Neon X Panel
Assembling Manual

Package Contents

Sylfirm X Neon Sign

Sylfirm X Neon X Body

x1

Components

Legs

x2

## Sylfirm X Neon X Components

Power Cords

x2

How to Assemble

1. Place two legs and hook the Sylfirm X Neon X onto the legs.
2. Grab the cables attached on the bottom area of the Sylfirm X Neon Sign and run the cables to the back of the wall backdrop. (You can find the existing drill hole on the bottom center area of the backdrop or drill a new hole to run the cable through)
3. In the back space of the backdrop wall, connect it with the Power Cords and plug the Power Cords into the outlet.

Picture below shows the final design

Back

Hanging Neon Sign
Assembling Manual

Package Contents

Hanging Neon Sign=

Hanging Neon Sign

#Sylfirmxusa

x1

Components

*Power drill and drill bits are not included.

Screw
(2 inch (50 mm))

x2

Power Cable

Power Cord

x1

How to Assemble

Sequin Wall

1. If possible, find an existing drill hole (about 0.5") to run the cable to the back side of the backdrop. If not, you will need a drill bit to drill a hole.
2. Position the neon sign and find a appropriate placement. Attach it to the backdrop wall by drilling
3. Run the cable attached to the hanging neon sign goes behind the backdrop wall. Connect it with Power cable and Power Cord.
4. Plug the Power Cord into the outlet.

Picture below shows final design

Haning Neon on a Sequin Wall

3.4ft W x 4.29ft H
# LED Counter Table
Assembling Manual

LED Counter Table

| LEC Counter Table	Acrylic Cover	Key
EXOSOME by BENEV		
x1	x1	x1

How to Assemble

1. Place the LED counter table where the outlet is. Make sure the outlet is postitioned in the middle of the LED counter table. Unlock the door on the left side of the LED counter table with the key .
2. Pull the cord out from the hole on the bottom and plug in to the outlet.
3. Place the acrylic cover on the top of the LED counter table.

Picture below shows final design

# 1.11ft W x 5.9ft H
Smart Mirror
Assembling Manual

BENEV
Global partner in medical aesthetics

Package Contents

Smart Mirror   *Power drill and drill bits are not included.*

Smart Mirror
(Size)

x1

Components

Mirror Stand

Cord

Cord

Screw

x2

How to Assemble

1. Attach the hook to the back of the mirror using 2 screwes.
2. Place the mirror stand. Mount the smart mirror to the stand and make sure to hook it to the stand.
3. Insert the plug with out the pin into the socket on back of the mirror, and connect the other end to the power outlet.
4. Turn on the power on the bottom of the mirror.

Picture below shows the final design

Back

2.25ft W x 4.5ft H
# Exosome Neon Bottle Panel
Assembling Manual

BENEV
Global partner in medical aesthetics

Package Contents

Exosome Neon Bottle

Exosome Neon Bottle Body

x1

Exosome Neon Bottle Components

Power Cord

x1

Components

Legs

x2

How to Assemble

1. Place two legs or hook the Exosome Neon Bottle on to the legs.
2. Grab the cable attached on the bottom area of the Exosome Neon Bottle and run the cable to the back of the backdrop wall. (You can find the existing drill hole on the bottom center area of the backdrop or drill a new hole to run the cable through)
3. In the back aread of the backdrop, connect the cable with the Power Cord and plug the Power Cord in the outlet.

Picture below shows final design

Back